

ASSEMBLY INSTRUCTIONS





CONTENT






MOUNTING THE INCLINATION ADAPTER





MOUNTING THE INCLINATION ADAPTER





MOUNTING THE STAND





MOUNTING THE MUSIC HOLDER



Mounting the music holder by tightening the M10 screw with the hex key



ADJUSTABLE HEIGHT





ADJUSTABLE ANGLE

