

**Quick Start Guide**

This quick start guide contains important information on the safe operation of the product. Read and follow the safety advices and instructions given. Retain the quick start guide for future reference. If you pass the product on to others please include this quick start guide.

**Safety instructions**
**Intended use**

This device serves as a multi-functional substructure for positioning a wide variety of devices or objects. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

**Danger for children**


Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts from the product. They could swallow the pieces and choke! Never let children unattended use electrical devices.

**Where to use the product**

Never use the product

- in conditions of extreme temperature or humidity
- in extremely dusty or dirty areas
- at locations where the unit can become wet

**General handling**

- To prevent damage, never use force when handling the product.
- Never immerse the product in water. Just wipe it with a clean dry cloth. Do not use liquid cleaners such as benzene, thinners or flammable cleaning agents.

**Setup**

1. On delivery, the legs of the frame are folded:



Lay the stand on its side, fold out your legs and place the stand on its feet.

2. This is how the stand should look like now:




3. Now push the two fold-up locks in the direction of the frame interior.




**ATTENTION!**  
**CRUSHING**  
**HAZARD!**

4. To widen the support surface, loosen the 4 hand screws shown in the illustration and pull out the right and left parts of the frame to the desired width. Then tighten the hand screws again.



5. To increase the height of the stand, you can loosen the screw latches on the four frame legs counterclockwise, then pull them away from the leg and pull the extensions out of the legs in the desired length. Let the latches snap back and tighten them again.



6. Optionally available accessories, like e. g. Fun Generation Universal Stand Extension (item # 437439) can be mounted on the two attachment points:



7. The folding of the stand is done in reverse order.

**Technical specifications**

■ Dimensions (packed):	860 mm × 460 mm × 665 mm
■ Dimensions (set up):	1275 mm × 515 mm × 910 mm
■ Height:	670- 910 mm

■ Weight:	7.4 kg
■ Load capacity:	50 kg



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.



The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains. In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.