



Steel frame

Upholstery: 70 mm

Height-adjustable in 16 steps

Height: 546 – 673 mm

Collapsible

Seating surface: 584 x 305 mm

Weight: 5.4 kg


max. load capacity: 90 kg

Seat material: faux leather black

To set the desired seat height, first loosen the connecting screw of the two crossbars.



Then slide both retaining bolts under one side of the keyboard bench in the direction of arrow ① and move the support tube ② to the centre of the bench to raise the seating area. Move it in the opposite direction to reduce the seat height. Let the retaining bolts slide back into the appropriate opening. Proceed on the other side of the bank accordingly.



This device is intended to be used as a seat when playing keyboards or similar musical instruments. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.



Ensure that plastic bags, packaging, etc. are properly disposed of and are not in the reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the product. They could swallow the pieces and choke! Never let children use electrical devices unattended.



The plasticiser contained in the rubber feet of this product may possibly react with the coating of your parquet, linoleum, laminate or PVC floor and after some time cause permanent dark stains. In case of doubt, do not put the rubber feet directly on the floor, but use felt-pad floor protectors or a carpet.



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling. Ensure that plastic bags, packaging, etc. are properly disposed of. Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.